

VINYL STAIR INSTALLATION

- Ensure the substrate is clean, dry and dust free.
- Beginning on the bottom step.
- Measure the Length and width of the riser. (for best results, use a stair gauge tool)
- Cut the riser material to length before ripping to desired width.
- Apply flooring adhesive to riser substrate and spread using a manufacturer recommended "V" notch trowel.
- Firmly press riser material onto substrate and tap lightly with a rubber mallet to ensure proper glue adhesion.
- Measure the length of stair tread. (For best results use a stair gauge tool)
- Cut stair nosing and tread plank to length.
- Apply flooring adhesive to tread substrate and spread using a manufacturer recommended "V" notch trowel.
- At the same time, in an "S" pattern apply a heavy bead of adhesive to the back of the stair nosing and along the front edge of the tread substrate.
- Connect the stair nosing and tread plank together ensuring the ends are flush.
- Firmly press the stair nosing and tread plank onto tread substrate and lightly tap with rubber mallet for proper glue adhesion. Ensure stair nosing is pushed tight to riser.
- Clean off any glue squeeze out immediately.
- Repeat process for remainder of stairs.

NOTE:

- Installation should be done by a qualified professional.
- **Polyurethane construction adhesives are not recommended when installing vinyl stair nosings. Instead use a dedicated flooring adhesive.**

WOOD STAIR INSTALATION

- Ensure the substrate is clean, dry and dust free.
- Beginning on the bottom step.
- Measure the Length and width of the riser. (for best results, use a stair gauge tool)
- Cut the riser material to length before ripping to desired width.
- Apply flooring adhesive to riser substrate and spread using a manufacturer recommended "V" notch trowel.
- Firmly press riser material onto substrate and tap lightly with a rubber mallet to ensure proper glue adhesion.
- Measure the length of stair tread. (For best results use a stair gauge tool)
- Cut stair nosing and tread plank to length.
- Apply flooring adhesive to tread substrate and spread using a manufacturer recommended "V" notch trowel.
- At the same time, in an "S" pattern apply a heavy bead of adhesive to the front edge of the tread substrate.
- Connect the stair nosing and tread plank together ensuring the ends are flush.
- Firmly press the stair nosing and tread plank onto tread substrate and lightly tap with rubber mallet for proper glue adhesion. Ensure stair nosing is pushed tight to riser.
- Clean off any glue squeeze out immediately.
- Repeat process for remainder of stairs.

NOTE:

- Installation should be done by a qualified professional.